Installation Instructions for CardToolTM Application Updater



About This Guide

This document describes the process of installing an application flash updater for CardScribe, CardDemo, CardVisor or CardDB.

Installation Instructions

There are 5 steps to updating the flash memory in the CardTool reader with a new application.

- 1. Ensure that the CardTool reader is installed in the expansion slot of the Handspring Visor
- 2. HotSync the flash updater application into the Handspring Visor. Note: Hot syncing is described in the Handspring user manual available on the Handspring CD or in the support section at <u>www.handspring.com</u>.

The Palm Desktop application must be installed on a PC. Shown below is the main screen of the Palm Desktop software (on the green Handspring CD) with the Install Icon circled in Red

	View Iools Hot≦ync Help Øsend					chim	himneysweep_CA								
A	Go to Today Vednesda	y]							_						
Date	Wednesday, February 11, 2004	•	Fel	1		0.00	D04		0.040	Ma		2.2	20		•
100		3	M 2	3	¥	Th 5	F	S 7	\$ 23	M	2	₩ 3	Th 4	F 5	6 6
S.	8 am		9	10		12	13	14	7	8	9	10	11	12	13
Address	om	15	16	17	18	19	20	21	14	15	16	17	18		20
1111000	9	22	23	24	25	26	27	28	21	22	23	24	25		27
1		29	1	2		4	5	6	28	29	30	31	1	2	
To Do	10		8	.9	10	-11	12	13	<u>(</u>)	5	-6	7	8	9	相
<i></i>					-	T F		Ê.		T	4.11				100
	1000		Addre	ess		Tol	10	j.		, R	41			5	
Memo	11	Na	me							Prin	nary				Ca
		Te	ch S	uppo	øt					ww	w.ha	ndsp	ring.c		Ur
	12 pm														
	Point and a second se														
4	1														
9	1														
Kpense															
ixpense	1								[•
xpense									[•
xpense	1 2 <u>New Event</u> Edit Event	•	Lo	ok u	ıp: [[•
ixpense		- 1	Lo	ok u	ıp: [[Har	rdspr	ing.	FOI

By clicking on the 'Install' icon on the left menu bar or by double clicking on the updater.prc file (if the *.prc files are associated with the Palm Desktop), the 'Install tool' will launch. Show below is the Install Tool Dialog box.

ser: chimneysweep_C4	stalled on your handheld the next]
ie you perform a HotSync ile Name] <u>A</u> dd
		<u>H</u> emove
		Done
lips:	tions to install on your handheld at	
340 B		

Make sure the correct HotSync user name is selected and that the updater file is shown in the main window. Shown below is the install tool prepared to load the CardDB3.2.prc updater file.

er: chimneysweep_	CA 💆]
(s) listed below will be e you perform a HotSy	installed on your handheld the next nc operation:	
ile Name	File Size	
ardDB3.2.prc	128K	<u>R</u> emove.
ips: ? Find other appli	cations to install on your handheld at	<u>D</u> one

Once the correct updater file present in the main window, hit the 'Done' button. The following message will appear.

i on your handheid.
ext time you perform a H red file(s) will be installed

Click on the OK button, put the Handspring Visor into the HotSync Cradle (with the CardTool reader inserted into the expansion slot) and hit the HotSync button. This should install the updater file in the Visor's memory and the updater icon should be visible on the main application screen. (Make sure the category is 'ALL' in the top right corner of the screen when looking for the new application)

If Hot syncing does not work, there is an excellent trouble shooting section for common HotSync problems in the support section of the Handspring Site. Try visiting the <u>www.handspring.com</u> and in the support section, search for '**Why can't I synchronize my** handheld with my desktop computer?' It is the top FAQ and what we use to trouble shoot hot syncing issues.

3. Locate the updater application icon on the Main screen. Depending on the application and version, the name will vary but it will typically have the same icon (see below) and the name will end with "Upd" (i.e. Updater). Note: CardDB updaters typically start with '3cardDB' and then have additional characters specific to the customer.




Locate Updater Icon on Main Screen (CardVisor updater)



Main Icon Screen with Updater Icon circled (CardScribe updater)

Once the updater is running, the main screen of the Updater application should display. If the CardTool reader is not installed, a warning message will be displayed. Both screens are shown below.



4. Tap on the 'Update Now' button.

After the Update Now button has been tapped, a screen will show the progress as the program erases and reprograms the flash memory. This normally takes less the 20 seconds.

5. When the update complete message displays, remove and reinsert the CardTool reader. The process is complete. The new application should automatically launch.

Congratulations, you've updated your CardTool reader!

Copyright

Printed in the United States of America

3511 Silverside Rd. Suite 105 Wilmington, DE 19810 www.TokenWorks.com

Copyright 2002, 2003, 2004 TokenWorks, Inc.

Information in this document is subject to change without notice. No part of this document may be reproduced or transmitted in any form or by any means, electronic or mechanical, for any purpose, without the express written permission of TokenWorks, Inc.

TokenWorks, CardTool, CardScribe, CardDB, and CardVisor are trademarks of TokenWorks, Inc. Visor and Handspring are trademarks of Handspring Inc.

Document Information

EVOLUTION OF THE DOCUMENT							
Date	Author	Evolution					
08/28/02	PC	First draft of Installation Instructions					
11/07/02	CC	Changed screen graphic to show CardVisor updater					
2/5/03	CC	Revised Updater name for CardDB version 3.					
2/11/04	СС	Revised with detailed Palm Desktop/Install Tool directions.					
	08/28/02 11/07/02 2/5/03	Date Author 08/28/02 PC 11/07/02 CC 2/5/03 CC					