
CardVisor® ID Scanner Software User Manual

AGE VERIFICATION APPLICATION





Copyright

Copyright 2002 -> 2009 TokenWorks, Inc. Printed in the USA

Information in this document is subject to change without notice. No part of this document may be reproduced or transmitted in any form or by any means, electronic or mechanical, for any purpose, without the express written permission of TokenWorks, Inc.

www.TokenWorks.com (Company Web Site)

www.CardVisor.com, www.IDVisor.com, www.IDScanner.com (Product Web site)

TokenWorks[®], CardVisor[®], CardTool[®], IDVisor[®] (pending) are trademarks of TokenWorks, Inc.

Palm, Hotsync, Visor® and Handspring® are trademarks of Palm Inc.

Table of Contents

COPYRIGHT	2
TABLE OF CONTENTS	3
ABOUT THIS DOCUMENT	4
DOCUMENT FORMAT	4
IDVISOR SCANNER HARDWARE	6
CARDVISOR SOFTWARE	
KEYWORDS, DEFINITIONS, AND JARGON	7
DOWNLOADING DATA FROM THE ID SCANNER TO A PC	9
INSTALL PALM DESKTOP PC SOFTWARE FROM PALM	9
SYNCHRONIZE YOUR ID SCANNER WITH YOUR COMPUTER	17
REGISTER YOUR ID SCANNER DEVICE (SKIP THIS SECTION)	23
INSTALL ADDITIONAL SOFTWARE (SKIP THIS SECTION)	25
EXPORTING FROM PALM DESKTOP & IMPORTING TO MICROSOFT EXCEL	28
METHOD 1. EXPORTING DATA FROM A PC PALM DESKTOP – USING MEMOPAD2CSV	
Introduction	
Software Installation	
Installing Main MemoPad2CSV Program	
Running Memopad2CSV Conversion Utility	34
METHOD 2. EXPORTING DATA FROM A MAC OR PC PALM DESKTOP – ORIGINAL METHOD	
1. How to extract and export your Memo data	
2. How to Import MemoPad Data to Microsoft Excel – The Original Method (cont'd)	
DELETING DATA FROM YOUR ID SCANNER	
Verify your data first!	
If your data doesn't verify	
Two ways to delete data from your ID Scanner	
Deleting Data directly on ID Scanner Deleting Data directly on ID Scanner Deleting Data directly on ID Scanner	
Deleting Data via Palm Desktop using HotSync Manager	
ENCODED STRIPE (MAGNETIC & BAR CODE) – FORMATS & RELIABILITY	53
FORMATS	53
Reliability	53
AGE VERIFICATION CALCULATION LIMITATIONS.	
STATE AND LOCAL PRIVACY LAWS, ORDINANCES OR RULES	54
DOCUMENT INFORMATION	55
APPENDIX	56
HOTSYNC TROUBLESHOOTING	56
HOW TO REINSTALL THE CARDVISOR SOFTWARE	56
IDVisor Z22 Mobile/CounterTop/MSR	56
CardVisor II, III, IV – Edge, BC, BC-Pro	
HOW TO REMOVE OUTLOOK AS THE DEFAULT HOTSYNC PROGRAM	58
LIMITED WARRANTY - CARDTOOL® READER AND/OR CARDVISOR® SOFTWARE	60


About This Document

Thank you for becoming a TokenWorks customer. We appreciate your business and we are happy to help you get the most value from our products.

First, we recommend that you print this document, place it in a 3-ring binder, and keep it handy with your other business operations manuals. That way, you will have a hardcopy where you can write any notes needed for your particular business.

This document tells you:

- How to install the Palm Desktop software on your PC so you can *import* data from your ID Scanner.
- How to *export* data from the Palm Desktop to an Excel compatible file.
- How to *delete* data from your ID Scanner and synchronize it with your computer.
- How to troubleshoot any unexpected synchronization situations you may encounter.



For success with this documentation, all you need to do is follow the checklist instructions, step-by-step. If you should encounter problems with synchronizing your PC and the ID Scanner, you will find step-by-step troubleshooting procedures in the Appendix.

Document Format

We formatted this document with 1-½ spaces between lines to leave room for you to write notes or personal reminders. We also provided all necessary screenshots so you'll know what to look for as you go along. It takes a few more pages to provide this format, but the clarity is worth every penny – and you won't strain your eyes on fine print and tiny screenshots.

The Acrobat PDF file includes bookmark navigation, active links to cross-reference parts of the document, plus active links to the Internet.

Each step-by-step instruction starts with "___" on the left-hand side as shown below. Indented under each step, you will typically find supporting information plus screenshots of dialog boxes that apply to that step. Here's an *example* of how the checklist format is laid out (don't take this step now):

___ Insert the Orange Palm Z22 CD into your PC's CD drive.

This version of the Palm Desktop software will (... comments and information as required for this step ...). When you insert the Orange CD, your PC will launch the installation screens below.



(... more information and screenshots as required for this step ...)
(Next step.)
(... information and screenshots as required for this step ...)
(Next step.)
(... etc. ...)

Using the checklist format shown above, we have attempted to include all necessary steps, even the "obvious" steps, to help those who might be new to computer experience. However, we assume that you know such things as how to:

- Use your PC or Mac operating system
- Navigate your computer's file system
- Surf the Internet
- Download software from the Internet (if required)

IDVisor Z22 CounterTop

Deluxe (or

CardVisor I, II, III, IV)

CardVisor I,

II, III, IV - BC

IDVisor Scanner Hardware

The IDVisor Scanner is the hardware that scans ID cards; it referred to herein as the "ID Scanner." The IDVisor Scanner comes in several models as shown to the right.

CardVisor Software

Each model of the IDVisor Scanner runs some version of the CardVisor Software, which comes in different versions as follows:

The CardVisor Software is provided as a basic version with optional upgrades as follows:

1. CardVisor II Basic Package,

to someone else in line).

- 2. CardVisor III Upgrade to VIP/Banned List Database,
- II, III, IV -3. CardVisor IV Upgrade Anti Pass-Back Alarm (detects more than 1 card scan on the same ID per evening, intended to tell you when someone passes back their ID

DVisor Z22

IDVisor Z22

CardVisor I,

Cardvisor I,

II, III, IV -

All IDVisor Scanners ID Scanners have been preloaded with CardVisor Software. Therefore, you don't need to install software on your PC to operate the IDVisor Scanners. (If that software has been accidentally erased or compromised, see How to Reinstall the **CardVisor Software** for instructions on how to reinstall the software).

However, you must install software on your PC to download the scan-transactions from your ID Scanner. Thus, you will use the Orange Palm CD to install the Palm Desktop software on your PC.

Later, you will run this Palm Desktop software to download your customer data from your ID Scanner.

Note: Some customers choose not to download scan-transaction data because the scanner automatically manages the last 6000 or 9000 scans by overwriting the oldest scans. These

customers choose to wait until an external event such as law enforcement requests a copy of the transaction data.

The White CardVisor CD contains user documentation plus utilities you will use to create your VIP/Banned lists if you have the upgrade to CardVisor III or IV Software. If you have the VIP/Banned list software, check this CD for the user manual and PC software used with the VIP/Banned List.

There are several versions of the Palm Desktop. We ship Palm Desktop version 4.14 on the orange CD. For older versions of the Palm Desktop and for Vista installations, visit http://www.idscanner.com/help/HotSyncIssues.htm

Keywords, Definitions, and Jargon

Term	Definition
CardTool® Reader	The CardTool reader is a 3-Track Magnetic Card Reader for the Palm Handspring Visor Handheld computer. It transforms any Handspring Visor into a portable magnetic card reader.
CardVisor Software	Software included with your IDVisor Scanner; see CardVisor Software on page 6 .
Delimit	To set the limit of something. Ex: The (^) character delimits (separates) fields, for example: name^address
Download	Transfer data from the ID Scanner (or Internet) to your PC
Help from the TokenWorks website	If you have any problems with your ID Scanner go to our help page at: http://www.idscanner.com/help/
	If you have any problems with HotSync, see HotSync Troubleshooting and/or check our Help page at: http://www.idscanner.com/help/
HotSync	The process of synchronizing the IDVisor Scanner's data with you PC's data.
HotSync Troubleshooting	If you have any problems with HotSync, see HotSync Troubleshooting and/or check our Help pages at: http://www.idscanner.com/help/ and
TD 0	http://www.idscanner.com/help/HotSyncIssues.htm
ID Scanner	Shorthand for the IDVisor Scanner AND its CardVisor Software.
Palm Desktop Application	PC software that communicates with the Palm Device.
PC	Personal Computer. In this manual, PC refers to either a

	Macintosh or PC computer.
PDA	Personal Digital Assistant. A generic term for a small, handheld computer. The Palm devices are often called PDAs.
Troubleshooting	For help with troubleshooting HotSync or your ID Scanner go to our help page at: http://www.idscanner.com/help/
Upload	Transfer data <i>from</i> your PC to your ID Scanner (or to the Internet)




Downloading Data from the ID Scanner to a PC

Install Palm Desktop PC Software from Palm

The flowchart to the right shows what you will achieve by following the steps in this section.

- Install Palm Desktop software. Here, you install Palm's software for communicating with your ID Scanner.
- Then, you will HotSync your ID Scanner with your computer, which means that the data will match.
- The next two steps are optional (not necessary).

You will use the Palm Desktop Application on the Orange Palm CD to transfer data to/from your PC and your ID Scanner (which is a Palm handheld computer). The Palm Desktop application has the same applications found on your ID Scanner.



Your ID Scanner stores card-swipe transactions in the *MemoPad* application.

Also installed with the Palm Desktop is a program called the *HotSvnc Manager*. When the *HotSync Manager* is running, you will see its icon **0** in the system task tray located in the bottom-right corner of your PC screen. HotSync Manager must be running (i.e. displayed in the system tray) to perform a HotSync.

Insert the Orange Palm Z22 CD into your PC's CD drive.


Note: If you have previously installed the Palm Desktop Version 4.01 for the Handspring Visor that we shipped on a Green CD, please read this.


This newer version 4.1.4 of the Palm Desktop software will overwrite older versions, even if you create a second administrative account. (In other words, you cannot have both versions running on the same PC.) However, version 4.1.4 does support the Handspring Visor.

NOTE: If you are using the *Vista* Operating System, please visit http://www.idscanner.com/help/HotSyncIssues.htm.

When you insert the Orange CD, your PC will launch the installation screens below.








As s	uggested	in the	dialog	box	above,	close	all	currentl	y r	unni	ng
appli	cations.										


Click Next.

___ Read the license agreement below.




Click the radio button that says I accept these terms.


(Without your acceptance, the Palm software will not install.)



Click Next to continue installation.



- ____ Uncheck the *Download latest settings...* (unless you want to receive Palm's marketing materials).
- Click Next
- ____ Notice the *Install Location* shown in the dialog box below.




Note: If the install location displayed above is C:\Program


Files\Handspring, then a previous version of the Palm Desktop is installed on your PC, AND if you click Next, this current installation software will over-write your previous version. If this is a new installation, the default location will be C:\Program Files\Palm.

____ Click Next to accept the default Install Location shown above.


Note: First-time installs will default to C:\Palm directory, not \Handspring. The install process will begin as shown below.



____ Notice that the green progress indicator moves to the right until the Palm software installation is complete.







____ Notice that the dialog box above says you may need to restart your computer.

Typically, a restart is not required.

___ Click Finish to complete the software installation.

Synchronize your ID Scanner with your computer

The next steps will show you how to sync (HotSync) your ID Scanner with your PC.

___ Restart your PC if necessary.




___ Click Next to synchronize your ID Scanner with your PC.

You will see the following dialog box.



Click Create new user name.

Note: If this is a brand-new install, you will need to create a new name to get past this screen. However, whatever name you type won't be used because your IDVisor® ID scanner will already have a HotSync name of *IDVisor2*, *IDVisor3* or *IDVisor4* depending on which version of CardVisor software you have installed. When you click *Create new user name*, you will see the following dialog box.



___ Enter any new username.

___ Click Next.

If you have Microsoft Outlook installed on your PC, the following dialog box will display. This dialog box will help you specify your preference for the HotSync process.




____ Do NOT click the bottom radio button (Synchronize your device with both Outlook and Palm Desktop software) at this point.

Here's why: If you select Outlook, your card-swipe data will be stored in Outlook where it is difficult to export to Excel. If you have accidentally used the Outlook option, see instructions at How to Reinstall the CardVisor Software.

 Instead, click the <u>top</u>	radio button	Synchronize	your device	with	Palm
Desktop software.					

Click Next.

You will then see the following dialog box to sync your ID Scanner and your PC.



- Verify that you see the HotSync Icon in the bottom right corner of the PC screen (red/blue circular icon).
- Connect the HotSync Cable between your ID Scanner's USB port and your computer.
- Look for a "new device found" message on your computer. You will likely hear a "thunk" sound if your speakers are on. (If your computer doesn't recognize the device, try disconnecting and reconnecting the USB cable.)
- ___ Tap the HotSync Button on your ID Scanner (see the illustration in the dialog box above).
- Check the bottom right-hand corner of your computer screen for possible messages about finding a new device and installing the driver.

NOTE: There may be a delay because your computer is installing a HotSync driver. Often, installing a driver causes the HotSync process to time-out. Your computer might say something like, "couldn't connect to the scanner." Don't be alarmed; just tap the HotSync Button again.

This will bring up the following dialog boxes.








Click OK to continue.

Notice that your ID Scanner's User name will display in the dialog box.

(Example dialog box shows User name as *IDmsr4*. Your User name will likely be different.)



When the HotSync is complete, you will see the following registration dialog box.




Register your ID Scanner device (Skip this section).

Following are the instructions for optionally registering your ID Scanner with Palm if you want Palm to send you marketing material so please skip this section.

Register with Palm (optional).

If you click Skip, you will see the next dialog box to get a 2nd chance.




If you click Skip again, you will see the following dialog box.




Click Next

Install additional Software (skip this section)

After you have synchronized your ID Scanner, Palm gives you an opportunity to install additional software on your ID Scanner.




- Click Quit
- ____ Once Hotsync is complete, launch the Palm Desktop application.
- Set the User name to the one just created (see user name pull down menu in top right corner)



Click the MemoPad icon on the left menu bar.

Shown below is what the Main screen of the Palm Desktop with the Memo Pad active should look like.



- Check that the number of Memos matches the number of Memos in the ID Scanner. On the left, the Memo is highlighted and on the right are its contents.
- ____ Verify that you can see the SAME Memos on your ID Scanner by pressing the button labeled View Data on the ID Scanner.
- ____ If no memos are visible on the Palm Desktop, see the troubleshooting section at HotSync Troubleshooting.

Troubleshooting tip: If there are no Memos visible and the HotSync operation worked OK, <u>verify that Outlook is NOT the default program for syncing data</u>. If Outlook is the default program for syncing data, go to **HotSync Troubleshooting**.

Exporting from Palm Desktop & Importing to Microsoft Excel

The ID Scanner's CardVisor software saves its transactions as Memos in its MemoPad application. When you HotSync to your Palm Desktop, these Memos are copied directly to your PC or Mac computer's MemoPad.

There are two methods to move the Memo data from the Palm Desktop to Microsoft Excel.

- For PC users who use MemoPad: In 2007, MemoPad2CSV software for PC computers was introduced to help automate the export process. For instructions, see Method 1. Exporting data from a PC Palm Desktop Using MemoPad2CSV below.
- For Mac users: You will need to export the Memo data from the Palm Desktop to
 a file, then open the file using Microsoft Excel's Import Wizard. For instructions,
 see Method 2. Exporting data from a Mac or PC Palm Desktop Original
 Method.

Method 1. Exporting data from a PC Palm Desktop - Using MemoPad2CSV

Introduction

The ID Scanner's CardVisor software saves its transactions as Memos in its MemoPad application. When you HotSync to your Palm Desktop, these Memos are copied directly to your PC's MemoPad. *Reminder:* Vista users must **Method 2. Exporting data from a Mac or PC Palm Desktop – Original Method** below.

The MemoPad2CSV utility extracts Memo data from your PC's MemoPad and creates a *csv (Comma Separated Value) file, which Microsoft Excel can open.


(Without this MemoPad2CSV utility, you must manually extract and export Memo data to a text file, then import the text file into Microsoft Excel using Excel's Import Wizard. MemoPad2CSV automates the process for PC users.)

Note: MemoPad2CSV requires Microsoft .NET framework 2.0, which is automatically installed when MemoPad2CSV is installed.

Software Installation


Find the directory on the white CardVisor CD where the MemoPad2CSV setup application is located. It will be in the MemoPad2CSV directory.

Shown below is an example of this directory




- ___ Double click on the setup.exe file.
- If .NET framework is already installed on your PC then the screen shown in the **Installing Main MemoPad2CSV** section will be displayed. If so, skip to that section. If not, the screen shown below will be displayed. Continue below and follow prompts to install .NET framework.

Note: The .NET Framework 2.0 is in the dotnetfx directory on the CD shown above.



____ Press Accept to Continue

The following dialog box will display. Note installation can take a few minutes




Installing Main MemoPad2CSV Program


Once .Net is installed, the MemoPad Setup Wizard welcome screen will display.




Click Next




____ Accept the default folder and select 'Everyone', then hit Next




Click Next




Click Next



___ Wait



Click Close




Memopad2CSV program icon should be on desktop and in programs menu.

Click icon to launch Memopad2CSV.

Running Memopad2CSV Conversion Utility

___ Click on the Memopad2CSV icon, the following dialog box will display



____ Notice the Simple Step 1, Step 2,...Step 5 buttons. Just click on each button in order and the software will guide you through the process.


The information below is provided for your convenience and we STRONLY suggest you use these step 1, Step 2, ... Step 5 buttons for directions.

Below is an example if your using Palm Desktop version 4.14.

 _ Notice the Category Selection radio buttons at the top of the above dialog
box:
If you're using the ID Scanner to read <i>drivers licenses</i> , click the CardVisor Category radio button.
If you're using the ID Scanner to read <i>student IDs</i> , click the CardDB Category
radio button. Refer to the respective software manuals.

- Click the top Browse button to locate the memopad.dat file, located in the MemoPad directory under the HotSync User name directory, which is named whatever the HotSync User name is for that ID scanner.
- Next, to find the memopad file. Click on the Step 2 button to get detailed directions on how to find this file as it varies depending on what version of the Palm Desktop. For example, in Palm Desktop version 4.14, you click the top

Browse button and navigate to Program Files\Palm\[your HotSync User Name]. In the example below, the Hotsync User Name is memopad - see dialog box below.




You may have multiple HotSync user names in your Palm directory, so choose the user name that corresponds to the ID Scanner that has the data you want.

____ Select the MemoPad directory as shown above.

___ Click Open.

This example dialog box below shows the MemoPad directory below for the DrTV2 HotSync User name.




- Select memopad.dat as shown above.
- ___ Click Open.


The main screen of memopad2CSV will update the path as shown below.



- ___ Click the 2nd Browse button for the destination path.
 - The destination path tells the computer where to store the output file.
- Select a destination such as My Documents.
 - Here's an example showing My Documents as the destination folder.




After you select the destination folder, the main screen of memopad2CSV will appear as:



___ If desired, change the name of the output file, making sure the file extension remains "csv" (Comma Separated Value).

In the example below, the output file is LatestData.csv. Remember, the "csv" file-type allows the file to be opened directly by Excel or other programs that open Comma Separated Value files.



- Click Convert.
- ____ Wait for the confirmation screen to show.



- ___ Click OK.
- Navigate to the directory where you saved your csv file.
- Double-click on the csv file.
- ____ Verify that Microsoft Excel opens your csv file and that each field is in its own column.

Excel will automatically open the file IF you have associated Excel with *.csv files.

If Excel does NOT open the file (Excel is not associated with csv files), take the following steps.

- Open Excel
- ____ Select File/Open from the main menu.
- ___ Navigate to your csv output csv file.
- Click Open.
- ____ Verify that Excel opens the csv file and that each field is in its own column.

 Scanner.
You're done with exporting your data, skip to Deleting Data from your ID
Excel will automatically load it.
*csv files will now be associated with Excel files; when you double-click a csv file,

Method 2. Exporting data from a Mac or PC Palm Desktop - Original Method


The Palm Desktop application lets you export all or selected Memos in several common formats including comma delimited, tab delimited, and text. You should use text format since CardVisor puts field delimiters (^) in the data, which the import wizard of Excel and Access can recognize. The following instructions tell you how to do two things in order:

- 1. How to extract and export your Memo data into a text file, then,
- 2. How to *import* that text file into Microsoft Excel.


Important: Follow these steps carefully so that you get it right and avoid having to do it over. OK, let's get started.

1. How to extract and export your Memo data


Select	the memos to be exported by highlighting the desired memos.
For ex	ample, follow the directions below to export just the Memos that are
catego	rized with the "CardVisor" Category.
Set the	e Category to "CardVisor" - See Category box circled in RED.



- Place your cursor anywhere in the 'Description' window and right-click to open a drop-down menu as shown above.
- ____ Choose 'Select All', as shown above (red circle in middle).
- ___ From the main File menu, select Export as shown below.




This action will launch the Export dialog box shown below.



__ In the Export dialog box, select the file folder where you want to save the export file. (See top red rectangle.)

Use the Pull Down arrow if you want to change directories.

At File name, enter your file name. (We have used <i>testcardvisorcategory.txt</i>
as shown above.)
NOTE: We recommend a file name that contains the scan-date(s) of the captured
transaction data. (Examples: Saturday022809 or 022809.) This will help you
identify the file later.
Set the Export type as Text (*.txt). (See 1 st red circle above.)
Important: Verify that the file extension is ".txt" and not ".csv" since files with
the "csv" file extension will not launch Excel's Import Wizard. If you accidentally
use csv, change the csv file extension to txt via the file manager. No harm will be
done.
Click the Range button for <i>Currently selected records</i> . (See 2 nd red circle
above.)
Click Export.
A dialog box will ask which field(s) of the Memo Pad should be exported, as shown
below.



___ Notice the three fields in the Memo Pad application; *Memo, Private and Category*.

- Memo contains track data this is the data you want to export.
- Private specifies whether the Palm OS should treat the record as private.
- *Category* specifies Memo category, i.e. CardVisor or raw data not necessary to export.

 Check	Memo	ONLY	to	export	the	track	data.

Unch	eck /	Priv	ate
\mathbf{c}		111	uιc.

____ Uncheck Category.

___ Click OK.

After this window closes, the data will be exported and saved to the export file you specified. The Export complete message will display.




___ Click OK.

NOTE: At this point you have extracted and exported your MemoPad data as a .txt file. Now, you must continue with the next steps to *import* that data into Excel.


2. How to Import MemoPad Data to Microsoft Excel – The Original Method (cont'd)

The data exported from the Palm Desktop (see above) delimits fields with the carat character (^). Many 3rd party marketing firms prefer to receive contact data in Excel spreadsheet format. Also to create mailing labels using the provided mailing label application note (see White CardVisor CD), it is necessary to import the data to Microsoft Excel. For this example, Excel will be used because the mailing label application notes are based on it. However, both Excel and Access Import Wizards are the same.

___ Click File/Open as shown below.




The Open dialog box will display as shown below.




- ____ Select the directory that contains your exported MemoPad data.
- ___ Change File of type to Text Files (*.prn, *.txt, *cvs)
- Select the correct file (in this example, export.txt) or type the correct file name into the File name text box.
- ___ Click Open.

This will launch the Excel Import Wizard as shown below. This Wizard lets you specify how Excel will import your data to the Excel spreadsheet. (Notice that the Wizard's blue title bar says, "Step 1 of 3." The following instructions will guide you through these 3 steps.



- ___ Click the Delimited radio button as shown (small red circle).
- ____ Select Start import at row 1 (small red ellipse).
- ____ Select File origin as Windows (ANSI) (larger red ellipse).
- Click Next.


This will launch the Wizard's Step 2 of 3 dialog box, shown below, which asks how fields are delimited.



- ____ IMPORTANT: Uncheck the *Tab*, *Space*, *Semicolon*, and *Comma* radio buttons.
- ____ Check only the 'Other' radio button as shown above.

Type a carat (^) into the 'Other' delimiter text box as shown above (red
ellipse).
Note: When you enter the carat character, the Wizard will put vertical lines in the
Data preview window so you can see how fields are separated.
Verify that the vertical lines separate the fields properly.
If the lines do not show up in the correct places, verify that only the Other radio
button is checked - and that all other radio buttons are unchecked.
If there are other errors in field separation, try again. Return to Method 2.
Exporting data from a Mac or PC Palm Desktop – Original Method.
Click Next


This will launch the Wizard's Step 3 of 3 dialog box, as shown below, where you can specify the data format for each column.



Notice that you can highlight a column of data and specify a format (General, Text, Date, or Do not import) for each column.
 Note: For mailing labels, General is fine on all columns. If certain information should be treated differently, this screen lets you format it appropriately.
 For our purposes, General will suffice.

Click Finish.

The data has now been imported into Excel. Shown below is what the imported data will look like in Excel.




Note: Each entry has its own row, with:

- First name in column A,
- Last name in column B,
- Address in column C, etc
- Also note that there are blank rows between each row. (We will remove those momentarily.)


____ To remove the empty rows in the data, click the Sort button. Or select Data/Sort to sort the entire spreadsheet.

Here is the spreadsheet after you click the Sort button



Click File/Save to save your new Excel spreadsheet.

This will launch the Save As dialog box shown below.



Enter your desired File name and Save as type.

In the example shown above,

- Save as file type is Microsoft Excel Workbook (*.xls), (red ellipse), and
- File name is 'export.xls.'
- You're done with exporting your data, skip to **Deleting Data from your ID**Scanner

Deleting Data from your ID Scanner

Verify your data first!

Before you delete the data on your ID Scanner, you must verify that you

• Downloaded *all* the ID Scanner data to your Palm Desktop AND

- Exported your ID Scanner data to a text file as described above. Here's how to
- Exported your ID Scanner data to a text file as described above. Here's how to verify:

 Open the exported file with	a text editor	such as Notepac	d (part of Windows),
and,			

Verify that the first and last lines in the exported file match the first and last memos in the ID Scanner's MemoPad application.

If they match, congratulations! It is now safe to delete the data in your ID Scanner.

Proceed to Two ways to delete data from your ID Scanner.

If your data doesn't verify

 _ If the first and last lines in the exported file do NOT match the first and last
memos in the ID Scanner's MemoPad application there's an error
somewhere. Do NOT delete the data from your ID Scanner!

___ Make sure you exported all the data properly before you delete the data from the ID Scanner.

Either:

- Your data didn't get exported properly in, or,
- Your data didn't get *imported* properly.

___ Check the export file created in 1. How to extract and export your Memo data.

If there is NO data:

- You may need to re-HotSync at Synchronize your ID Scanner with your computer, or,
- You may need to re-import at 1. How to extract and export your Memo data

____ If there IS data, you must redo 2. How to Import MemoPad Data to Microsoft Excel – The Original Method (cont'd).

Two ways to delete data from your ID Scanner

There are two ways to delete the data from the ID Scanner. (Instructions below.)

- 1. Delete the data directly on the ID Scanner via built in menu (easiest way to delete if you don't want to download your ID Scanner data to your PC), or
- 2. Use the Palm Desktop & HotSync manager.

Here are the instructions for both ways:

1. Deleting Data directly on ID Scanner

Tap on CardVisor on the top left corner of the main CardVisor	screen.
---	---------

From the men	u options	select	Admin/Delete	Transactions	as shown	below

Options	
F Name:	Delete Transactions
. Name:	
DOB:	
AGE: 0	Exp: See I.D.
Status:	
ID #:	Sex:
Note:	
Scan or Swi	pe a license

Follow	the	prompts.
--------	-----	----------

 _ If you downloaded your ID Scanner transactions to your Palm Desktop, <u>also</u>
<u>delete them from your Palm Desktop – or they will reappear during the next</u>
HotSync!

2. Deleting Data via Palm Desktop using HotSync Manager

Us this approach if you plan to download the ID Scanner data to your Palm Desktop as it will ensure the PC and the ID Scanner transaction logs stay in sync.

_				
Open	the	Palm	Desktop	Application.
 - - -	• • • •	. •		

 Select the HotSync user name	for the ID	Scanner	you want to	delete	data
from.					

If you have multiple HotSync names for the same PDA, select the one used during the last HotSync.

Select the MemoPad icon (left side of screen).
You will see the Memos appear on the main screen.
Highlight the Memos you want to delete. (Select Edit Menu/All, or click one Memo, hold down the mouse key, and drag down across the Memos you want to delete.)


Select Edit Menu/Delete or hit the Del key on your keyboard.

The following dialog box will appear.



- If you have NOT EXPORTED your data to a text file, <u>check Archive deleted</u> items at next HotSync. If you HAVE EXPORTED your data to a text file, <u>uncheck Archive deleted items at next HotSync</u>. (See above dialog box.)
- Perform another HotSync with the ID Scanner <u>use the same HotSync name used above.</u>

This will erase the data on your ID Scanner. If you checked *Archive deleted items at next HotSync*, then the software will create MemoPad Archive (MPA) files (*CardViso.MPA & RawData.MPA*) in the MemoPad directory for that HotSync name. See below.



If you mistakenly deleted your MemoPad data, you can recover the last set (only) of deleted data by using these *.MPA files. You can open these archive files with the Palm Desktop software and merge them with an existing MemoPad transaction list. See the Palm Desktop software user manual for details.

Encoded Stripe (Magnetic & Bar Code) – Formats & Reliability

Formats

The CardVisor ID Scanner reads encoded information off the encoded (magnetic or 2D bar code) stripe of drivers license or ID card.

While most states have the same basic information on the encoded stripe, the locations and format differ. From time to time, states will change how they encode the information on the stripe. Also, since most do not read what they've encoded, they sometimes make mistakes that become part of the issued-card population. This may cause difficulty in parsing the data.

When the software is unsure, it creates a memo in the MemoPad application that starts with the phrase "Trouble Parsing this data ->..."

If you see a Memo like this, then please email it to support@tokenworks.com or email the entire MemoPad file (*MemoPad.dat*) and you will be one of the first to receive a software update that addresses this new license format.

Reliability

Driver licenses are exposed to varying conditions in a typical 4 to 6 year life cycle. Unlike credit cards, Driver licenses are not frequently swiped nor are they typically replaced if the encoded stripe is damaged. Therefore, scan-performance will vary with older licenses in poorer condition.

For licenses with Magnetic stripes, it is possible to read only Track 2 of a license since it is encoded at a lower bit density than tracks 1 and 3, and less sensitive to damage. Track 2 has the driver's license number, date of birth and expiration date. If the name does not appear on the screen, it is possible that Track 1 is unreadable while track 2 is still readable. **Note:** The software must be able to read track 2 information to display the age and card status.

For licenses with 2D bar codes, verify that the bar code is not damaged and that all foreign material is removed before reading. The level of error correction incorporated into the bar code varies between states so some states will scan with quite a bit of damage while others will fail with minor damage.

Age Verification Calculation Limitations

The CardVisor application is warranted to read the date of birth information encoded on the machine-readable (magnetic or 2D bar code) stripe and display the current age based on current date/time information contained in the handheld computers real time clock (RTC). It will also read other information on the stripe and present it to the operator. It should be understood that the displayed age may differ from the actual age of the person presenting the card for any one of a number of reasons. Among the most likely are:

- The card does not belong to the person presenting it,
- The encoded machine-readable stripe has been altered,
- The date of birth presented to the issuing authority was misrepresented,
- The issuing authority mis-encoded the date of birth on the card,
- The handheld computer real time clock is not set to the current date/time.

The above list of reasons is not exhaustive.

State and Local Privacy Laws, Ordinances or Rules

Some states and local government units regulate whom, how and what information from a driver's license can be electronically viewed or recorded. Check with the authorities in your jurisdiction before using the CardVisor product. Purchaser is wholly responsible for insuring full compliance with the laws of the jurisdiction wherein the product is to be used. TokenWorks fully disclaims any liability for any loss, damages or untoward circumstances that may arise from the inappropriate use of the product or of the data retrieved through its use.

Document Information

EVOLUTION OF THIS DOCUMENT			
Version	Date	Author	Evolution
UM-032107-CC-R0	03/21/2007	CC	Initial Release – Updated Palm Desktop installation section of CardVisor Software manual
UM-032107-CC-R1	06/28/2007	CC	Added ListMaker and MemoPad2CSV sections
UM-032107-CC-R2			(No data)
UM-032107-CC-R3	03/15/09		Update/reorganize/reformat in checklist format
UM-032107- CC-R4	4/1/09	CC	Reformatted to checklist format, moved VIP/Banned List to new document, expanded MemoPad2CSV section.
UM-032107- CC-R5	5/1/09	CC	Updated for MemoPad2CSV 1.2 which works with Palm Desktop ver 6.2
UM-032107- CC-R6	7/15/09	CC	Clarified MemoPad2CSV installation directions & MemoPad2CSV usage instructions
UM-032107- CC-R6	1/15/09	CC	Formatting / Color Changes

Appendix

HotSync Troubleshooting

For the latest illustrated troubleshooting tips for HotSync see: http://www.idscanner.com/help/HotSyncIssues.htm

How to Reinstall the CardVisor Software

IDVisor Z22 Mobile/CounterTop/MSR

Your ID Scanner comes with the CardVisor software installed in memory. If the software has been erased or compromised, you must reinstall/update the software in one of two ways described below:

If you have previously HotSynced your ID Scanner, simply HotSync again and when prompted, select the previous Hotsync name to automatically reinstall the software.
OR
If you have NOT previously HotSynced your ID Scanner:
Download the software from our Support Downloads section – see instructions at http://www.idscanner.com/support/Download.htm AND,
Use the Palm Desktop Install Tool to install the software on your ID Scanner via the Hotsync Process.
Once the Hotsync process completes, the software will be installed.
If you tap on the icon, the program will launch, but it is quicker if you associate the buttons on the front panel of the Palm with the CardVisor application and the MemoPad application. You can do this by:
Select the Prefs icon and,
Tap on the buttons item to associate these programs with the buttons.


CardVisor II, III, IV - Edge, BC, BC-Pro

The CardVisor software comes pre-installed in the CardTool Magnetic Card reader (Black Plastic Magnetic Card Reader inserted into expansion slot of Handspring Computer).

In the highly unlikely event the software has been erased or compromised, you must reinstal
the software as follows:
Download the software from our Support Downloads section – see
instructions at http://www.idscanner.com/support/Download.htm AND,
Use the Palm Desktop Install Tool to install the software on your ID Scanner
via the Hotsync Process.
Run the updater software on the Palm computer.
The updater software will program the flash memory of the CardTool reader and
install new software.

How to Remove Outlook as the Default HotSync Program

- ___ Open the Palm Folder.
- Open the PIM Conduit Sync folder and notice that two options display, "Sync with Outlook" and "Sync with Palm Desktop" as shown below.



____ Select the Sync with "Palm Desktop" Option.

	-	4.1	11 10
Inen	perform	another	HotSvnc.

Verify that your data appears in the Memos section.

If you want further information about Switching between Outlook and Palm Desktop synchronization, visit Palm's site at

http://kb.palm.com/SRVS/CGI-

BIN/WEBCGI.EXE?New,kb=PalmSupportKB,t=ooccase,case=obj(25263)

Table 1. Palm Desktop vs. PC Operating System

Palm Desktop Version by Palm Device/PC Operating System				
Device	Operating System	Palm Desktop	Comments	
	Win98, Win2000, WinXP, MAC	Version 4.14	Palm Desktop Version 4.14 works great on Win2000 and WinXP	
Palm Z22 (IDVisor Z22 Mobile, CounterTop, MSR)	Win VISTA	Palm Desktop Version 4.14 or Version 6.2	Palm Desktop Version 4.14 installs on some <i>Vista</i> machines and if it works, great. If Palm Version 4.14 fails, then install palm Version 6.2. NOTE: Since MemoPad2CSV does not work with Palm Desktop Version 6.2, you must use the original or manual export process detailed in this manual to convert data from Palm Desktop to a comma separated value (csv) file. (As of this date 4/9/2009 this is true, but we have started work on making memopad2CSV compatible with the Palm Desktop 6.2 so please visit http://idscanner.com/help/HotsyncIssues.htm and check for an update.)	
Handspring	Win98, Win2000, WinXP	Palm Desktop Version 4.01 or 4.14	Palm Desktop 4.14 does not officially support Handspring devices, but we and our customers have found Version 4.14 works great and is actually faster and more robust than 4.01.	
Visor (Deluxe, Edge, Pro)	Win VISTA	Try Palm Desktop Version 4.14 but <i>Vista</i> is not supported.	Palm Desktop Version 4.14 installs on some <i>Vista</i> machines and if its works, great. If not, you have two choices. Move to another PC with WinXP/Win2000 or try to down grade to WinXP/Win2000. Try to install 4.01 on <i>Vista</i> see below.	

If you have any problems with HotSync, see **HotSync Troubleshooting** and/or check our Help page at: http://www.idscanner.com/help/

www.IDscanner.com, www.IDVisor.com

Limited Warranty - CardTool® reader and/or CardVisor® software

TokenWorks™ Inc. (hereafter "TokenWorks") warrants the TokenWorks CardTool® reader, the CardVisor® software, and this Manual, hereafter jointly or individually the "product" IN ITS ENTIRETY, to be in good working order for a period of 90 days from the date of purchase. Should this product fail to be in good working order at any time during this warranty period, TokenWorks will, at its option, repair or replace this product at no additional charge except as set forth below. Repair parts and replacement products will be furnished on an exchange basis and will be either reconditioned or new. All replaced parts and products become the property of TokenWorks. This limited warranty does not include service to repair damage to the product resulting from accident, disaster, misuse, abuse, or modification of the product performed without the prior written approval of TokenWorks.

Limited Warranty service may be obtained by sending the product during the warranty period to TokenWorks. Before sending material, please obtain a Return Material Authorization (RMA) number by requesting one from TokenWorks. To obtain additional return and contact information, visit www.tokenworks.com. If this product is to be returned you agree: (a) to insure the product or assume the risk of loss or damage in transit; (b) to prepay shipping charges to the warranty service location, and (c) to use the original shipping container or equivalent.

ALL EXPRESS AND IMPLIED WARRANTIES FOR THIS PRODUCT, INCLUDING THE WARRANTIES OF MERCHANTABILITY AND FITNESS FOR PARTICULAR USE, ARE LIMITED IN DURATION TO A PERIOD OF 90 DAYS FROM THE DATE OF PURCHASE, AND NO WARRANTIES, WHETHER EXPRESS OR IMPLIED, SHALL CONTINUE BEYOND SUCH PERIOD. EACH PURCHASER UNDERSTANDS THAT THE TOKENWORKS PRODUCT IS OFFERED AS IS. TOKENWORKS AND ITS SUPPLIERS ASSUME NO RESPONSIBILITY FOR ANY DAMAGE OR LOSS CAUSED BY DELETION OF DATA AS A RESULT OF MALFUNCTION, DEAD BATTERY, OR

REPAIRS. BE SURE TO MAKE BACKUP COPIES OF ALL IMPORTANT DATA ON OTHER MEDIA TO PROTECT AGAINST DATA LOSS.

IF THIS PRODUCT IS NOT IN GOOD WORKING ORDER AS WARRANTED ABOVE, YOUR SOLE REMEDY SHALL BE REPAIR OR REPLACEMENT AS PROVIDED ABOVE. IN NO EVENT WILL TOKENWORKS BE LIABLE TO YOU FOR ANY DAMAGES, INCLUDING ANY LOST PROFITS, LOST SAVINGS OR OTHER INCIDENTAL OR CONSEQUENTIAL DAMAGES ARISING OUT OF THE USE OF OR INABILITY TO USE SUCH PRODUCT OR FOR ANY CLAIM BY ANY OTHER PARTY, IRRESPECTIVE OF ANY NOTICE TO TOKENWORKS OF THE POSSIBILITY OF SUCH DAMAGES OR CLAIM. THIS WARRANTY GIVES YOU SPECIFIC LEGAL RIGHTS. YOU MAY ALSO HAVE OTHER RIGHTS, WHICH VARY FROM STATE TO STATE.

---- End of Document ----